



12 or 24 VDC depending on version

5 K pot

Notes:

1. Although it is possible, it is not recommended to reverse operation while the motor is spinning.
2. Use 5K Ohm potentiometer to PW (wiper), PL and PH
3. Fuse accordingly to match load
4. Mount with adequate airflow to assist in cooling. Use 4, 6-32 standoffs one on each of the four corners.
5. Do NOT expose control to water, high humidity or corrosive dust, salt and dirt.
6. Do not connect any terminal to earth ground.
7. Do not open "SW" while motor is spinning

TITLE 910-3522-078/080			
IPC RLVS F/R Hookup with POT input			
AUTHOR SJP			
DATE	4-21-09	SHEET 1	OF 1
REVISION	0		